

BEACON

LED Window Display

Quick Start Guide


1 what's in the box

Included with your Beacon system are:

- Beacon LED Display
- Mounting hardware
- USB Drive and Adapters



LED Display



! Please keep all packaging in the event you should need to return system for warranty service.

2 register your device

There are two ways to start your registration.

We recommend using Google Chrome with your Beacon Account

option 1

1. Scan QR code on back of sign



2. Follow the on screen instructions

option 2

1. In your browser, go to thinksign.com
2. Click **Account Login then** Indoor Sign Manager
3. Click Register New Account if you do not have an account (if you have an account, skip this step)
4. Login
5. Click **Register Device** and follow instructions



need help?

For details or support on creating content, sign installation, account admin and more, go to your Beacon dashboard and click Support

3

creating content

1. Login to your account
2. From the Beacon dashboard, Click **Edit Content**
3. Choose your device
4. Click **Continue**
5. Click **New Project**
6. You will be automatically taken to your first slide.
7. Design your slide content and save
8. Add additional slides to project
9. Load content to sign (see Quick Start step 4)




4

put content on sign

To put content on the sign, you will need to save the project file to a usb drive and load it on the sign. **We highly recommend using a laptop or desktop for this step.**

1. From Project Page, choose the project you wish to use
2. Click **Prepare Content For Sign**
3. Click **Generate USB File**
4. Once file is generated, click **Go To Download**
5. On Download Page, click **Download USB File**
6. Save downloaded file to USB Drive
7. Eject USB drive and insert it into the sign
8. Content will automatically load to sign
9. If you experience any issues, go to your Beacon dashboard and, click Support



5

installing your sign

! important !

1. Sign is intended to be installed **ONLY** in a dry, indoor location. **DO NOT** use outdoors.
2. We recommend using the mounting hardware provided with your sign.
3. Before installation, make sure any structure from which you will hang or mount the sign has been professionally rated to support the weight of your sign.
4. Ensure that you can meet the power requirements specified for your sign model.

Specifications

Model	W28C4U	W42C4U
Weight	17lbs	32lbs
Power	AC 120V/120W	AC 120V/275W

we're here to help!

For details or support on creating content, sign installation, account admin and more, go to your Beacon dashboard and click Support

